



Main 1/3 Schematic Diagram





Main 2/3 & CRT Schematic Diagram

CAUTION !


Fixed voltage power supply circuit is used in this unit.
If Main Fuse (F801) is blown, check to see that all components in the power supply circuit are not defective before you connect the AC plug to the AC power supply.
Otherwise it may cause some components in the power supply circuit to fail.

CAUTION

FOR CONTINUED PROTECTION AGAINST FIRE HAZARD,
REPLACE ONLY WITH THE SAME TYPE FUSE.


NOTE:

The voltage for parts in hot circuit is measured using hot GND as a common terminal.





1



CRT CBA Bottom View

